


# Cleaning Instructions for ScanSnap S1500/S1500M


#### **BEFORE CLEANING**

Open the ADF while pulling the cover open lever



It is recommended that these items be cleaned EVERY 1,000 SCANS

Consumables	Part Number
Consumable Kit	CON-3360-001A
Cleaning Kit	SC-CLE-SS



### Turn the Scanner OFF while cleaning the following locations

#### **Using F1 Impregnated Cleaning Wipes**

1 Pad Assy

Wipe downwards. When cleaning take care to prevent the cleaning wipe from catching on the metal parts

② ADF Glass Surfaces x 2

Located on the ADF cover and opposite side. Clean lightly.

3 Pick Roller


Clean lightly taking care not to scratch the surface.

4 Plastic Rollers x 4

Clean lightly while rotating with your finger. Take care not to roughen the surface.







#### Turn the Scanner ON while cleaning the following locations

## Using F1 Impregnated Cleaning Wipes

To rotate the Feed and Eject Rollers, press the POWER button while holding down the SCAN button. As a guideline, six presses of the POWER button makes the rollers rotate one full turn.



While holding down the SCAN button ①

Press the POWER button ②
Each press of the POWER button will cause the rollers to rotate

5 Feed Rollers x 4

Clean lightly while rotating with your finger. Take care not to roughen the surface.

6 Eject Rollers x 2

Clean lightly taking care not to roughen the surface.

For further information please refer to the ScanSnap S1500/S1500M Operators Guide which can be found on our Website: http://www.fujitsu.com/emea/products/



